

230 VAC MULTIFUNCTION CONTROL UNIT 051D

AB2101 VERSION
APE-570/0510 - with radio module
APE-570/0511 - without radio module



- Motor torque adjustment
- Slowdown (soft start)
- Obstacle detection
- Programmable outputs
- Multifunction inputs
- Positive or negative inputs
- Dead man's function
- Soft start
- 1 motor mode
- Flashing light 230 vac/vdc
- Photocells test
- Motors test
- Compatible with plug in Faac radio receiver
- Terminal block compatible with Faac 455d control unit
- Easy programming
- Diagnostic through display

Technical data:

- Motors: 600W each motors
- Flashing lamp: max 60W 230 VAC
- Power supply: 24 VDC max 250mA

 **USER MANUAL**

Abexo[®]
AUTOMATION ACCESSORIES

ABEXO is a registered trademark property of
AB TECNO srl - Via Cicogna 95
40068 San Lazzaro di Savena (BO)
info@abtecono.com
www.abexo.tech



SUMMARY

SAFETY INFORMATION	3	OBSTACLE SENSOR PROGRAMMING	18
230V CONNECTIONS - MOTORS AND FLASHING LAMPS	4	AUTOMATIC OBSTACLE SENSOR PROGRAMMING	18
INSTALLATION LAYOUT	5		
TYPICAL SWING GATE INSTALLATION	5	FUNCTION OVERVIEW	19
		AUTO-CLOSE TIME	19
INPUTS CONNECTION - NEGATIVE COMMON	6	PEDESTRIAN TIME	19
INPUTS CONNECTION - POSITIVE COMMON	7	KICK BACK FUNCTION AT CLOSING	19
		PRE-BLINKING TIME	19
TERMINAL BLOCK SETTINGS	8	KICK BACK FUNCTION AT OPENING	19
INPUTS - NEGATIVE OR POSITIVE COMMON	8	STEP-BY-STEP MODE	19
TERMINAL BLOCK 9 - E1 - N.O.	8	COMMUNITY MODE	19
TERMINAL BLOCK 10 - E2 - N.O.	8	STANDARD MODE	19
TERMINAL BLOCK 11 - E3 - N.C.	8		
TERMINAL BLOCK 12 - E4 - N.C.	8	FUNCTION OVERVIEW	20
TERMINAL BLOCK 13 - E5 - N.C.	8	FAST CLOSURE	20
TERMINAL BLOCK 14 - E6 - N.C.	8	PHOTOCELLS LOGIC: SLIDING	20
		ELECTRIC LOCK / FLASHING LAMP	20
TERMINAL BLOCK SETTINGS	9	OIL RECYCLING / MOTOR HEATING	20
TERMINAL BLOCK 22 - E7 - N.C.	9	ONLY MOTOR A MODE	20
TERMINAL BLOCK 23 - E8 - N.C.	9		
TERMINAL BLOCK 24 - E9 - N.C.	9	FUNCTION OVERVIEW	21
		RESTORING MANOEUVRE WITH DEAD MAN FUNCTION	21
MENU NAVIGATION	10	WORKING CYCLES LIMIT - MAINTENANCE REQUEST	21
USEFUL TIPS	10	WORKING CYCLES COUNTER	21
EXAMPLES	10		
GUIDED CONFIGURATION	11	TEST	22
GUIDED CONFIGURATION 1 OR 2 MOTOR(S)	11	PHOTOCELLS TEST	22
		MOTORS TEST	22
OVERVIEW: FUNCTIONS AND REPORTS	12		
		REMOTE CONTROLS CONFIGURATION	23
FACTORY SETTINGS	13	(only for control units with radio module - APE-570/0510)	
RESTORE FACTORY SETTINGS	13	STORE A REMOTE CONTROL	23
FACTORY SETTINGS: PARAMETERS	13	ERASE/DELETE A REMOTE CONTROL	23
OPERATIONAL REPORTS AND PRIORITIES	14		
		REMOTE CONTROLS CONFIGURATION	24
MOTOR A SETTINGS	16	(only for control units with radio module - APE-570/0510)	
STANDARD TIME	16	ERASE/DELETE ALL REMOTE CONTROLS	24
SLOWDOWN TIME	16	PROGRAMMABLE FUNCTIONS	24
SOFT START (achieving set torque)	16		
DELAY AT CLOSING (MOT. A)	16	PLUG-IN RADIO (both versions)	24
TORQUE ADJUSTMENT/STANDARD FORCE	16		
TORQUE ADJUSTMENT/SLOWDOWN FORCE	16	PROGRAMMABLE OUTPUTS	25
STANDARD OBSTACLE TRESHOLD	16	PROGRAMMABLE OUTPUTS - 1 AND 2	25
SLOWDOWN OBSTACLE TRESHOLD	16	Example: remote control configuration - controlling a courtesy light	25
		Example: configure a remote control to signal a dead man opening movement	25
MOTOR B SETTINGS	17	Example: configure a remote control to signal a dead man closing movement	25
STANDARD TIME	17	Example: transforming a 230VAC light into a flashing lamp	25
SLOWDOWN TIME	17		
SOFT START (achieving set torque)	17	PRODUCT DISPOSAL	29
DELAY AT CLOSING (MOT. B)	17		
TORQUE ADJUSTMENT/STANDARD FORCE	17		
TORQUE ADJUSTMENT/SLOWDOWN FORCE	17		
STANDARD OBSTACLE TRESHOLD	17		
SLOWDOWN OBSTACLE TRESHOLD	17		

WARNINGS FOR THE INSTALLER - GENERAL SAFETY INSTRUCTIONS

1. Read the instructions carefully before installing the control unit.
2. Keep these instructions for future reference.
3. This product has been designed and manufactured exclusively for the use intended and indicated in this documentation. Any other use not expressly indicated could compromise the integrity of the product and/or constitute a source of danger.
4. For the safety of all persons, the instructions given in this manual must be carefully followed. Incorrect installation or use of the product can cause serious personal injury.
5. Packaging materials must not be left within the reach of children, as they are potential sources of danger, and must be properly disposed of.
6. AB Tecno Srl declines all responsibility for any consequences arising from improper use or use other than that for which the device was designed and constructed.
7. AB Tecno Srl shall not be held liable for non-compliance with current EC standards in the construction of the motorised closing device, or for any deformation that may occur during use.
8. Do not install the appliance in an explosive atmosphere: the presence of flammable gases or fumes constitutes a serious safety hazard.
9. Installation must be carried out in accordance with standards EN 12453 and EN 12445. For non-EU countries, in order to achieve a sufficient and adequate level of safety, the above-mentioned standards must be observed in addition to the individual national regulatory references.
10. Before carrying out any work on the system, disconnect any batteries and switch off the power supply.
11. An omnipolar switch with contact opening distance equal to or greater than 3 mm should be installed on the power supply of the automatic gate. The use of a 6A thermomagnetic circuit breaker with omnipolar switch is recommended.
12. Check that there is a differential switch with a 0.03A threshold upstream of the system.
13. Check that the earthing system is properly installed and connected to the metal parts of the enclosure.
14. Also the correct operation of the automated devices with an internal anti-crushing safety function must be checked in accordance with the standards indicated in point 9.
15. The safety devices (standard EN 12978) protect any danger areas from mechanical risks related to movement, such as crushing, dragging, shearing and lifting.
16. For each system, we recommend the use of at least one warning light (e.g. flashing light), as well as an appropriately fixed and clearly visible warning sign.
17. AB Tecno Srl declines all responsibility concerning the safety and proper operation of the automatic gate, in the event that components not manufactured by AB Tecno Srl are used when installing the system.
18. The installer must provide the End User with all information concerning manual operation of the automatic gate in the event of an emergency.
19. Do not allow children or other persons to stand near the system during operation.
20. Keep any remote control or triggering device out of the reach of children to prevent unintentional operation of the automatic gate.
21. The transit of people and vehicles is only permitted when the automatic gate is fully open.
22. The user of the automatic gate must refrain from any attempt at repair and/or direct intervention and must contact qualified personnel only. Otherwise, AB Tecno Srl declines all liability for any consequences.
23. Anything not expressly provided for and indicated in these instructions is not permitted.

230V CONNECTIONS - MOTORS AND FLASHING LAMPS



GENERAL		
PE	N	L
GROUND	NEUTRAL	PHASE


MOTOR A (600 W - 230 VAC)		
1	2	3
COMMON	OPEN	CLOSE

MOTOR B (600 W - 230 VAC)		
4	5	6
COMMON	OPEN	CLOSE


LIGHT (60 W - 230 VAC)	
7	8
COMMON	OPEN

INSTALLATION LAYOUT

TYPICAL SWING GATE INSTALLATION





The system must have a physical limit in the opening and closing movement



INPUTS CONNECTION - NEGATIVE COMMON



To set the inputs with negative common, E0 = 02



To use the PHOTOCCELL TEST FUNCTION, connect the negative pole of the transmitters to the "t1" terminal block and activate this function with $L0 = 02$

INPUTS CONNECTION - POSITIVE COMMON

To set the inputs with positive common, E0 = 01



To use the PHOTOCCELL TEST FUNCTION, connect the negative pole of the transmitters to the "t1" terminal block and activate this function with **E1=4**

TERMINAL BLOCK SETTINGS

Each terminal block is linked to a parameter: they can all be identified with letter **E**.

E0 INPUTS, NEGATIVE-POSITIVE COMMON	2 NEGATIVE	E5 TERMINAL BLOCK 22 - E5	n AUTO-ENABLE
E1 TERMINAL BLOCK 9 - E1	G0 START	E6 TERMINAL BLOCK 23 - E6	n AUTO-ENABLE
E2 TERMINAL BLOCK 10 - E2	PE PEDESTRIAN	E7 TERMINAL BLOCK 24 - E7	n AUTO-ENABLE
E3 TERMINAL BLOCK 11 - E3	n AUTO-ENABLE	E8 TERMINAL BLOCK 25 - E8	n AUTO-ENABLE
E4 TERMINAL BLOCK 12 - E4	n AUTO-ENABLE	E9 TERMINAL BLOCK 26 - E9	n AUTO-ENABLE

E0 INPUTS, NEGATIVE-POSITIVE COMMON

The inputs of the terminal blocks can be set both in NEGATIVE and POSITIVE COMMON.

To select **NEGATIVE COMMON** (terminal block 14, 15, 16 with tag -) set **E0 = 2**.

To select **POSITIVE COMMON** (terminal blocks 17, 18 with tag +) set **E0 = 1**.

E1 TERMINAL BLOCK 9 - E1 - NORMALLY OPEN

Terminal block 9 is associated with a **normally open (N.O.)** contact. The parameters that can be set are:

n DISABLED, **G0** START, **PE** PEDESTRIAN, **P0** OPEN DEAD MAN, **Pc** CLOSE DEAD MAN, **EL** ELECTRIC LOCK.

E2 TERMINAL BLOCK 10 - E2 - NORMALLY OPEN

Terminal block 10 is associated with a **normally open (N.O.)** contact. The parameters that can be set are:

n DISABLED, **G0** START, **PE** PEDESTRIAN, **P0** OPEN DEAD MAN, **Pc** CLOSE DEAD MAN, **EL** ELECTRIC LOCK.

E3 TERMINAL BLOCK 11 - E3 - NORMALLY CLOSED

Terminal block 11 is associated with a **normally closed (N.C.)** contact. The parameters that can be set are:

n DISABLED, **5t** STOP. This control unit is supplied with the standard setting where **terminal block 11** is disabled (**E3 = n**). When a **NORMALLY CLOSED** contact is connected to **terminal block 11**, it is automatically detected by the control unit that sets the parameter of the terminal block to the correct safety function, in this case **E3 = 5t** STOP. This feature is called **AUTO-ENABLE**.

E4 TERMINAL BLOCK 12 - E4 - NORMALLY CLOSED

Terminal block 12 is associated with a **normally closed (N.C.)** contact. The parameters that can be set are:

n DISABLED, **tc** CLOSING PHOTOCELL - MODE 1, and **td** CLOSING PHOTOCELL - MODE 2. This control unit is supplied with the standard setting where **terminal block 12** is disabled (**E4 = n**). When a **NORMALLY CLOSED** contact is connected to **terminal block 12**, it is automatically detected by the control unit that sets the parameter of the terminal block to the correct safety function, in this case **E4 = tc** CLOSING PHOTOCELL - MODE 1. This feature is called **AUTO-ENABLE**.

E5 TERMINAL BLOCK 13 - E5 - NORMALLY CLOSED

Terminal block 13 is associated with a **normally closed (N.C.)** contact. The parameters that can be set are:

n DISABLED, **tc** CLOSING PHOTOCELL - MODE 1, and **td** CLOSING PHOTOCELL - MODE 2. This control unit is supplied with the standard setting where **terminal block 13** is disabled (**E5 = n**). When a **NORMALLY CLOSED** contact is connected to **terminal block 13**, it is automatically detected by the control unit that sets the parameter of the terminal block to the correct safety function, in this case **E5 = tc** CLOSING PHOTOCELL - MODE 1. This feature is called **AUTO-ENABLE**.

E6 TERMINAL BLOCK 14 - E6 - NORMALLY CLOSED

Terminal block 14 is associated with a **normally closed (N.C.)** contact. The parameters that can be set are:

n DISABLED, **A0** LIMIT SWITCH OPENING MOTOR A. This control unit is supplied with the standard setting where **terminal block 14** is disabled (**E6 = n**). When a **NORMALLY CLOSED** contact is connected to **terminal block 14**, it is automatically detected by the control unit that sets the parameter of the terminal block to the correct safety function, in this case **E6 = A0** LIMIT SWITCH OPENING MOTOR A. This feature is called **AUTO-ENABLE**.

TERMINAL BLOCK SETTINGS

E7

TERMINAL BLOCK 22 - E7 - NORMALLY CLOSED

Terminal block 22 is associated with a **normally closed (N.C.)** contact. The parameters that can be set are:

n **DISABLED**, **Ac** **LIMIT SWITCH CLOSING MOTOR A**. This control unit is supplied with the standard setting where **terminal block 22** is disabled ($E7 = n$). When a **NORMALLY CLOSED** contact is connected to **terminal block 22**, it is automatically detected by the control unit that sets the parameter of the terminal block to the correct safety function, in this case $E7 = Ac$ **LIMIT SWITCH CLOSING MOTOR A**. This feature is called **AUTO-ENABLE**.

E8

TERMINAL BLOCK 23 - E8 - NORMALLY CLOSED

Terminal block 23 is associated with a **normally closed (N.C.)** contact. The parameters that can be set are:

n **DISABLED**, **ob** **LIMIT SWITCH OPENING MOTOR B**. This control unit is supplied with the standard setting where **terminal block 23** is disabled ($E8 = n$). When a **NORMALLY CLOSED** contact is connected to **terminal block 23**, it is automatically detected by the control unit that sets the parameter of the terminal block to the correct safety function, in this case $E8 = ob$ **LIMIT SWITCH OPENING MOTOR B**. This feature is called **AUTO-ENABLE**.

E9

TERMINAL BLOCK 24 - E9 - NORMALLY CLOSED

Terminal block 24 is associated with a **normally closed (N.C.)** contact. The parameters that can be set are:

n **DISABLED**, **ob** **LIMIT SWITCH OPENING MOTOR B**. This control unit is supplied with the standard setting where **terminal block 24** is disabled ($E9 = n$). When a **NORMALLY CLOSED** contact is connected to **terminal block 24**, it is automatically detected by the control unit that sets the parameter of the terminal block to the correct safety function, in this case $E9 = ob$ **LIMIT SWITCH OPENING MOTOR B**. This feature is called **AUTO-ENABLE**.

The standard setting of inputs is negative common $E0 = 02$. To set the inputs with positive common, change to $E0 = 01$.

E1 N.O.	E2 N.O.	E3 N.C.	E4 N.C.	E5 N.C.
n DISABLED	n DISABLED	n DISABLED	n DISABLED	n DISABLED
Go START	Go START	St (*) STOP	tc (*) CLOSING PHOTOCELL MODE 1	tA (*) OPENING PHOTOCELL
PE PEDESTRIAN	PE PEDESTRIAN		td CLOSING PHOTOCELL MODE 2	tc CLOSING PHOTOCELL MODE 1
oP OPEN	oP OPEN			
cL CLOSE	cL CLOSE			
Po OPEN DEAD MAN	Po OPEN DEAD MAN			
Pc CLOSE DEAD MAN	Pc CLOSE DEAD MAN			
EL ELECTRIC LOCK	EL ELECTRIC LOCK			

E6 N.C.	E7 N.C.	E8 N.C.	E9 N.C.
n DISABLED	n DISABLED	n DISABLED	n DISABLED
Ro (*) LIMIT SWITCH OPENING MOTOR A	Rc (*) LIMIT SWITCH CLOSING MOTOR A	ob (*) LIMIT SWITCH OPENING MOTOR B	ob (*) LIMIT SWITCH OPENING MOTOR B

N.O. = NORMALLY OPEN


N.C. = NORMALLY CLOSED

STANDARD TERMINAL BLOCKS CONFIGURATION OR WHEN RESTORED TO FACTORY SETTINGS

* N.C. inputs are disabled, as standard configuration: $E3 = E4 = E5 = E6 = E7 = n$.

When the inputs are connected, the control unit automatically sets them to the correct safety function.

MENU NAVIGATION



To select a parameter from the menu, use the arrows (←) (→). With KEY (←) you navigate the menu in one direction, while with KEY (→) in the opposite direction. Once you reached the desired parameter, the value will appear on the display. To edit the value of the chosen parameter, use KEY (+) or KEY (-), depending on the value you need to set. The new values are automatically SAVED when exiting the menu. To exit the menu press KEY (←) or (→) until the display shows - -. By keeping the key pressed, it is possible to exit the menu quickly.

USEFUL TIPS

1. If the parameter you need to edit is at the end of the list, you can use the KEY (←) to reach it faster, by moving in the opposite direction. To select a parameter that is at the beginning of the list, it is better to use KEY (→).
2. Keep the key pressed to move quickly through the parameters list.
3. To exit the menu, keep the KEYS (←) and (→) pressed until - - appears on the display.
4. All the values are automatically saved when exiting the menu. If no key is pressed for 60 seconds, the control unit automatically exits the menu and saves the parameters. If you are not sure of the changes made, switch off the control unit without exiting the menu: the changes made in this session will not be saved.
5. When you are not navigating through the menu, the display shows the operating function. If multiple function are active, the one with the higher priority is shown.
6. If new values have been saved, it is always possible to restore the standard configuration: this operation does NOT delete the previously saved transmitters (see "STANDARD CONFIGURATIONS").

EXAMPLES

Example 1: add 1 second to the STANDARD WORKING TIME - MOTOR A

We consider that the control unit has the standard configuration STAND BY - -.

- 1) Press KEY (→)
- 2) **A 1** appears on the display --> this value is the STANDARD TIME, motor A
- 3) After 2 seconds, the control unit shows the value on the display - for example **14** seconds
- 4) Press KEY (+), the display will show **15**
- 5) Press KEY (←) to exit the menu and save the set parameter **A 1 = 15** seconds

Example 2: disable auto-closure

- 1) Select AUTO-CLOSE TIME **F 0** using KEY (←) or (→). By keeping the arrows pressed it's possible to navigate the menu faster.
- 2) After 2 seconds, the control unit shows the value (**F 0**) on the display - for example **10** seconds
- 3) Keep KEY (+) pressed. The value will quickly increase, then **5t** will appear on the display: now, AUTO-CLOSE function is disabled and the gate will be open until the end of the opening movement (**5t** means STOP an the end of the opening movement).
- 4) Press KEY (←) or (→) repeatedly/keep them pressed to exit the menu and save the set parameter, until - - appears on the display.

EXAMPLE 3: restore standard configuration

- 1) Select **d 0** using KEY (←) or (→). By using (symbol) you will easily reach **d 0** (it is one of the last parameters in the list).
- 2) After 2 seconds (→) will appear on the display.
- 3) Keep KEY (+) pressed: the display will blink showing **4**.
2 seconds later, - - will appear on the display: default settings have been restored. The control unit automatically exits the menu. Now, you can release KEY (+).

GUIDED CONFIGURATION

In this section it is possible to set the motor working time or the obstacle detector threshold. These procedures can be identified by letter P: it is always possible to manually change the values at the end of the programming.

BEFORE STARTING:

- Check the gate: it must be fully closed
- Check that the motor rotation is correctly performed: both motors must open during the opening movement; both motors must close during the closing movement.
- Be sure to have a START device: for example a transmitter stored as (symbol) or a key-switch connected to **terminal block 9** with value **E 1 = G0** (START).
- In order to program the control unit without the slowdown working time, set: **A2** or **b2 = 00** and then proceed with programming. During the configuration phase, on the display you will see the parameter you are setting, for example, if the display shows **A 1** it means that the control unit is setting parameter **A 1** (STANDARD TIME - MOTOR A).

STORE A TRANSMITTER AS START DEVICE

1. Select parameter **r 1** using key (←) or (→).
2. After a few seconds (= _) will appear on the display
3. Keep the button of the transmitter you want to store pressed: the display shows (= _)
4. Press KEY (+): the display shows (= 1). Your transmitter **has been successfully stored** in position 1 in the control unit's memory (display = 2 means position 2 in the memory, display = 3 means position 3, etc up to 99).
 - 4a. If the display shows (= .) your transmitter **has not been stored**.
 - 4b. If the display does not show (= .), the control unit **did not receiver** your transmitter (E.G.: different frequency compared to the receiver), or the radio receiver is faulty.

P 1/P2

GUIDED CONFIGURATION: 1/2 MOTOR/S

P 1: configuration 1 motor mode **LS=4**, standard working time **A 1**, motor A slowdown time **A2** and auto-close time **F0**. To proceed with configuration **P 1** read lines **A 1**, **A2** and **F0**. If you disabled the slowdown time of the motor, skip **A 1** and/or **b 1**.

P2: motor A and motor B standard time **A 1/b 1**, slowdown time **A2/b2** and auto-close time **F0** configuration. If you disabled the slowdown time of one of the motors or both, ignore **A 1** and/or **b 1**.

--	After 2 seconds two dashes will appear on the display. Perform a START command to start A 1 configuration.
A 1	You are working on motor A STANDARD TIME . Motor A starts the opening movement. When the leaf controlled by motor A has completed 90% of the opening movement, send another START command. The control unit will automatically move to A2 configuration step
A2	You are working on motor A SLOWDOWN TIME . Motor A slows down. It is advisable to wait 2-3 seconds when the leaf has come to a completely open position and the motor ended the opening movement, then issue a new START command. The control unit will automatically move to b 1 configuration step
b 1	You are working on motor B STANDARD TIME . Motor A stops and motor B slows down. When the leaf controlled by motor B has completed 90% of the opening movement, send a START command. The control unit will automatically move to b2 configuration step
b2	You are working on motor B SLOWDOWN TIME . Motor B slows down. It is advisable to wait 2-3 seconds when the leaf has come to a completely open position and the motor ended the opening movement, then issue a new START command. The control unit will automatically move to F0 configuration step
F0	You are working on AUTO-CLOSE TIME F0 . Both motors are idle. The display will show F0 , then the seconds counting. Count the desired time you want your automation to wait before starting the auto-closure operation, then press the START command

> **Guided configurations count the same time for opening and closing movements.**

> **If a leaf perform the SLOWDOWN operation only during opening movement (and not during the closing movement)**

follow this procedure:

- Select **A 1** using keys (←) or (→)
- Decrease **A 1** value by 1 second using key (-)
- Select **A2** using keys (←) or (→)
- Increase **A2** value by 3 seconds using key (+)
- Perform a complete cycle

If the slowdown movement is performed, your configuration has come to an end. If not, repeat this procedure. Use the same procedure for motor B, if needed.

OVERVIEW OF FUNCTIONS AND REPORTS

OPERATIONAL REPORTS	
Po	DEAD MAN OPENING
Pc	DEAD MAN CLOSING
St	STOP
Fh	PHOTOCELL OP + CL
tc	CLOSING PHOTOCELL MODE 1
td	CLOSING PHOTOCELL MODE 2
tA	OPENING PHOTOCELL
ih	LIMIT SWITCH ERROR BOTH MOTORS
EA	LIMIT SWITCH ERROR MOTOR A
Eb	LIMIT SWITCH ERROR MOTOR B
Go	START
PE	PEDESTRIAN
oP	OPEN
cL	CLOSE
EL	ELECTRIC LOCK
do	ACTIVATE OUTPUT
It	PHOTOCELLS TEST ERROR
7A	OBSTACLE DETECTION MOTOR A
7b	OBSTACLE DETECTION MOTOR B
9A	TEST ERROR MOTOR A
9b	TEST ERROR MOTOR B
9P	SENSOR PROGRAMMING ERROR
Ab	LIMIT SWITCH MOT.A + LIMIT SWITCH MOTOR B
Ao	OPENING LIMIT SWITCH MOTOR A
Ac	CLOSING LIMIT SWITCH MOTOR A
ob	OPENING LIMIT SWITCH MOTOR B
oc	CLOSING LIMIT SWITCH MOTOR B
--	STAND BY

A MOTOR A	
A1	STANDARD TIME
A2	SLOWDOWN TIME
A3	START TIME
A4	WAITING TIME BEFORE CLOSING
A5	STANDARD MOTOR FORCE
A6	SLOWDOWN MOTOR FORCE
A7	STANDARD OBSTACLE THRESHOLD
A8	SLOWDOWN OBSTACLE THRESHOLD

b MOTOR B	
b1	STANDARD TIME
b2	SLOWDOWN TIME
b3	START TIME
b4	WAITING TIME BEFORE CLOSING
b5	STANDARD MOTOR FORCE
b6	SLOWDOWN MOTOR FORCE
b7	STANDARD OBSTACLE THRESHOLD
b8	SLOWDOWN OBSTACLE THRESHOLD

t TESTS	
t1	PHOTOCELLS TEST
t2	MOTORS TEST

d FACTORY SETTINGS	
d0	RESTORING INITIAL VALUES

F/L GENERAL FUNCTIONS	
F0	AUTO-CLOSE TIME
F1	PEDESTRIAN TIME
F2	KICK BACK FUNCTION AT CLOSING
F3	PRE-BLINKING TIME
F4	KICK BACK FUNCTION AT OPENING
F5	STEP BY STEP
F6	MULTIPLE RESIDENTS
F7	FAST CLOSURE ON ALL CONTROLS
F8	PHOTOCELLS LOGIC: SLIDING
L0	ELECTRIC LOCK - FLASHING LIGHT
L1	MOTOR OIL RECIRCULATION
L3	ONLY MOTOR A MODE
L4	RESTORING MANOEUVRE WITH DEAD MAN FUNCTION
L5	WORKING CYCLES ASSISTANCE REQUEST
L6	TOTAL WORKING CYCLES COUNTER

r RADIO	
r0	GATE CODE
r1	START
r2	STOP
r3	PEDESTRIAN
r4	FAST CLOSURE
r5	DELETE ALL CODES
r6	PROGRAMMABLE FUNCTION
r7	PROGRAMMABLE FUNCTION
r9	PLUG-IN RADIO MODULE FUNCTION

E TERMINAL BLOCK FUNCTIONS	
E0	NEGATIVE-POSITIVE INPUT REFERENCE
E1	TERMINAL BLOCK INPUT 9
E2	TERMINAL BLOCK INPUT 10
E3	TERMINAL BLOCK INPUT 11
E4	TERMINAL BLOCK INPUT 12
E5	TERMINAL BLOCK INPUT 13
E6	TERMINAL BLOCK INPUT 22
E7	TERMINAL BLOCK INPUT 23
E8	TERMINAL BLOCK INPUT 24
E9	TERMINAL BLOCK INPUT 25

P GUIDED PROGRAMMING	
P1	GUIDED PROGRAMMING 1 MOTOR
P2	GUIDED PROGRAMMING 2 MOTORS
P6	OBSTACLE SENSOR PROGRAMMING

o PROGRAMMABLE OUTPUTS	
o1	RELAY MODULE FUNCTION PLUG-IN 1
o2	RELAY MODULE FUNCTION PLUG-IN 2

KEYS	
←	RUN FROM P6 TO A1
→	RUN FROM A1 TO P6
+	INCREASE / ENABLE
-	INCREASE / ENABLE

By holding the button down it is possible to scroll/increase/decrease quickly

FACTORY SETTINGS

The procedures that restore the factory settings can be identified on the menu by the letter **d**.



RESTORATION OF INITIAL PARAMETER SETTINGS

This procedure **DOES NOT DELETE** previously saved remote controls from the memory. To restore the initial settings:

1. Select the parameter **d0** using the keys (←) or (→).
2. After 2 seconds the symbol **n** will appear on the display.
3. Keep the (+) KEY pressed down: the display will flash showing **4**
4. After about 2 seconds the control unit shows **- -**: the factory values have been restored and the control unit will automatically exit from the menu. Now, you can release the (+) KEY.

INITIAL SETTING VALUES

MOTOR A		<i>description</i>	
A1	14 sec	STANDARD TIME	
A2	7 sec	SLOWDOWN TIME	
A3	0,8 sec	START TIME	
A4	0,6 sec	WAITING TIME BEFORE CLOSING	
A5	0,8 %	STANDARD MOTOR FORCE	
A6	10 %	SLOWDOWN MOTOR FORCE	
A7	n %	STANDARD OBSTACLE THRESHOLD	
A8	n %	SLOWDOWN OBSTACLE THRESHOLD	

MOTOR B		<i>description</i>	
b1	14 sec	STANDARD TIME	
b2	7 sec	SLOWDOWN TIME	
b3	0,8 sec	START TIME	
b4	0,3 sec	WAITING TIME BEFORE OPENING	
b5	0,8 %	STANDARD MOTOR FORCE	
b6	10 %	SLOWDOWN MOTOR FORCE	
b7	n %	STANDARD OBSTACLE THRESHOLD	
b8	n %	SLOWDOWN OBSTACLE THRESHOLD	

FUNCTIONS		<i>description</i>	
F0	10 sec	AUTO-CLOSE TIME	
F1	6 sec	PEDESTRIAN TIME	
F2	n y/n	KICK BACK FUNCTION AT CLOSING	
F3	1 sec	PRE-BLINKING TIME	
F4	n y/n	KICK BACK FUNCTION AT OPENING	
F5	n y/n	STEP BY STEP	
F6	n y/n	MULTIPLE RESIDENTS	
F7	n y/n	EXTENDED FAST CLOSURE	
F8	n y/n	PHOTOCELLS LOGIC: SLIDING	
L0	0 0,1,2,3	ELECTRIC LOCK	

FUNCTIONS		<i>description</i>	
L1	0 min	MOTOR HEATING / OIL RECYCLING	
L3	n y/n	1 MOTOR MODE	
L4	n y/n	RESTORING MANOEUVRE WITH DEAD MAN FUNCTION	
L5	n y/n	PERIODIC ASSISTANCE	

TESTS		<i>description</i>	
t1	n y/n	PHOTOCELLS TEST	
t3	4 y/n	MOTORS TEST	

RADIO		<i>description</i>	
r6	P0	DEAD MAN OPENING	
r7	Pc	DEAD MAN CLOSING	
r9	G0	PLUG-IN RADIO - START FUNCTION	

INPUTS		<i>description</i>	
E0	2	NEGATIVE INPUT REFERENCE	
E1	G0	TERMINAL 9 - START FUNCTION	
E2	PE	TERMINAL 10 - PEDESTRIAN FUNCTION	
E3	n	TERMINAL 11 - DISABLED	
E4	n	TERMINAL 12 - DISABLED	
E5	n	TERMINAL 13 - DISABLED	
E6	n	TERMINAL 22 - DISABLED	
E7	n	TERMINAL 23 - DISABLED	
E8	n	TERMINAL 24 - DISABLED	
E9	n	TERMINAL 25 - DISABLED	

PARAMETERS NOT DESCRIBED ON THIS PAGE ARE LINKED TO PROCEDURES AND THEREFORE DO NOT HAVE AN INITIAL VALUE.

OPERATIONAL REPORTS AND PRIORITIES

When you are not navigating through the menu, the display shows the operating function. If multiple functions are active, the one with the higher priority is shown. For example, **input 9** on the terminal block is associated with the function programmed on parameter **E 1**. The value **E 1** in the initial configuration is **E 1 = C0 START**. The **START** function is associated with a normally open contact; when the contact is closed, the control unit display shows **C0**, i.e. it indicates that an event has been generated that activates the **START** function. If shortly afterwards, a remote control button is pressed which has been stored with the function **r 2 STOP**. The control unit display shows **St STOP**, because the **STOP** function has a higher priority than the **START** function.

The following table lists all the operational functions that the control unit is able to manage, starting with the highest priority and ending with the lowest.

DISPLAY	NAME	DESCRIPTION	CONTROL SOURCE			
			TERMINAL BLOCK		REMOTE CONTROL	
P0	DEAD MAN OPENING	When the DEAD MAN OPENING function is active, the gate is open even if the STOP and PHOTOCELLS functions are active. When the DEAD MAN OPENING function is no longer engaged, the gate stops.	E 1 9	E 2 10	r 6	r 7
Pc	DEAD MAN CLOSING	When the DEAD MAN CLOSING function is active, the gate is closed even if the STOP and PHOTOCELLS functions are active. When the DEAD MAN CLOSING function is no longer engaged, the gate stops.	E 1 9	E 2 10	r 6	r 7
St	STOP	The STOP function is active. If the gate is moving, it will come to a stop.	E 3 11		r 2	
FS	OPENING PHOTOCELL+ CLOSING PHOTOCELL	The OPENING PHOTOCELL and CLOSING PHOTOCELL MODE 1 functions are active at the same time.	E 4 12	E 5 13		
Ec	CLOSING PHOTOCELL MODE 1	The CLOSING PHOTOCELL MODE 1 function reverses the movement during the closing phase and it has no effect during the opening phase. If the CLOSING PHOTOCELL MODE 1 function is active and the gate is stopped, it will NOT be started in OPEN when a START order is received.	E 4 12	E 5 13		
Ed	CLOSING PHOTOCELL MODE 2	The CLOSING PHOTOCELL MODE 2 function reverses the movement during the closing phase and it has no effect during the opening phase. If the CLOSING PHOTOCELL MODE 2 function is active and the gate is stopped, it will be started in OPEN when a START order is received.	E 4 12			
EA	OPENING PHOTOCELL	The OPENING PHOTOCELL function reverses the movement during the closing phase suspends opening during the opening phase.	E 5 13			
ih	LIMIT SWITCH ERROR MOTOR A and MOTOR B	The OPENING LIMIT SWITCH and CLOSING LIMIT SWITCH functions of motor A and motor B are active simultaneously. Motor A and motor B will not be able to move when both opening or closing.	E 6 22	E 7 23		
			E 8 24	E 9 25		
EA	LIMIT SWITCH ERROR MOTOR A	The OPENING LIMIT SWITCH and CLOSING LIMIT SWITCH functions of motor A are active simultaneously. Motor A will not be able to move when both opening or closing.	E 6 22	E 7 23		
EB	LIMIT SWITCH ERROR MOTOR A B	The OPENING LIMIT SWITCH and CLOSING LIMIT SWITCH functions of motor B are active simultaneously. Motor B will not be able to move when both opening or closing.	E 8 24	E 9 25		
C0	START	The START function can open and close the gate. Its operation also depends on the programming of the parameters made (FS = step-by-step mode / FB =multiple residents mode - see " GENERAL FUNCTIONS ") and on the status of the other inputs.	E 1 9	E 2 10	r 1	r 4

OPERATIONAL REPORTS AND PRIORITIES

PE	PEDESTRIAN	The PEDESTRIAN function can open and close door A of the gate for the time F 1 programmed. Its operation also depends on the programming of the parameters made (F 5 = step-by-step mode / F 6 = multiple residents mode - see "GENERAL FUNCTIONS") and on the status of the other inputs.	E 1 9	E 2 10	r 3
oP	OPEN	The OPEN function always starts the gate by opening depending on the status of the photocells, stop and limit switches.	E 1 9	E 2 10	r 6 r 7
cL	CLOSE	The CLOSE function always starts the gate by closing depending on the status of the photocells, stop and limit switches.	E 1 9	E 2 10	r 6 r 7
EL	ELECTRIC LOCK	The ELECTRIC LOCK function activates the electric lock for 3 seconds. The parameter L 0 must be set to the following values L 0 = 00 or L 0 = 0 1 .			r 6 r 7
do	ACTIVATE OUTPUT	The ACTIVATE OUTPUT function starts the function connected to the programmable outputs o 1 and o 2 . The output functions must be connected to the correct source (see PROGRAMMABLE OUTPUTS).			r 6 r 7
9P	AUTOMATIC PROGRAMMING ERROR	This error is reported after automatic programming of SENSOR P 6 . Error 9P indicates that one or more parameters related to the obstacle sensor have not been calibrated. To check which parameters are not programmed, check the value of the following parameters P 6 , P 7 , b 7 and b 8 (see "CONFIGURATION MOTOR A/B"). The parameters set to r have not been programmed.			
Ab	LIMIT SWITCH MOTOR A + LIMIT SWITCH MOTOR B	The function LIMIT SWITCH MOTOR A when opening or closing is active at the same time as the function LIMIT SWITCH MOTOR B when opening or closing. If the gate is fully closed and both closing limit switches (motor A and motor B) are installed, the display will show Ab subject to the priority of other events.	E 6 22	E 7 23	
Ao	OPENING LIMIT SWITCH MOTOR A	The function OPENING LIMIT SWITCH OF MOTOR A is active: it ends the stroke of motor A when opening.	E 8 24	E 9 25	
Ac	CLOSING LIMIT SWITCH MOTOR A	The function CLOSING LIMIT SWITCH OF MOTOR A ends the stroke of motor A when closing.			
o2	OPENING LIMIT SWITCH MOTOR B	The function OPENING LIMIT SWITCH OF MOTOR B is active: it ends the stroke of motor B when opening.			
oc	CLOSING LIMIT SWITCH MOTOR B	The function CLOSING LIMIT SWITCH OF MOTOR B ends the stroke of motor B when closing.			
--	STAND BY	No function is active, no event is detected			

MOTOR A SETTINGS

Motor A can be configured using 8 parameters identified by the letter **A**.

sec = seconds **%** = percentage parameter **n** = disabled

Times are expressed in seconds

Forces and thresholds are expressed in decimals and correspond to %. Ex: **01** = 10%

A1	STANDARD TIME	14 sec	A5	STANDARD FORCE (from 10% to 100%)	8/10 %
A2	SLOWDOWN TIME	7 sec	A6	SLOWDOWN FORCE (from 10% to 100%)	10/10 %
A3	SOFT START (ACHIEVING SET TORQUE)	0,8 sec	A7	STANDARD OBSTACLE DETECTION THRESHOLD	n %
A4	WAITING TIME BEFORE CLOSING	6 sec	A7	SLOWDOWN OBSTACLE DETECTION THRESHOLD	n %

A1	STANDARD TIME	MINIMUM: 00 sec	MAXIMUM: 99 sec
-----------	----------------------	------------------------	------------------------

Motor A works for **A1** seconds at force **A5**. At the end of this time, **motor A** slows down. This occurs during both opening and closing. **Motor A** opens before **motor B**. **Motor A** closes after **A4** seconds with respect to **motor B**.

A2	SLOWDOWN TIME	MINIMUM: 00 sec	MAXIMUM: 99 sec
-----------	----------------------	------------------------	------------------------

Motor A works for **A2** seconds at force **A6**. The slowdown phase is performed after the normal working time for both opening and closing. To disable the slowdown of **motor A**, set the parameter **A2 = 00 sec**. Setting the slowdown to zero also means that programming **A2** will be carried out without considering the slowdown phase of **motor A**.

A3	SOFT START (ACHIEVING SET TORQUE)	MINIMUM: 01 sec	MAXIMUM: 15 sec
-----------	--	------------------------	------------------------

When starting, **motor A** gradually increases the force until it reaches the set force **A5**. During this time the obstacle detection sensor is disabled.

A4	DELAY AT CLOSING (MOTOR A)	MINIMUM: 00 sec	MAXIMUM: b1+b2 sec
-----------	-----------------------------------	------------------------	---------------------------

At the end of the opening phase and after the automatic closing time **F0**, **motor B** starts the closing phase. After **A4** seconds, **motor A** also begins to close. This time is useful to avoid overlapping of the doors during the closing phase.

A5	TORQUE ADJUSTMENT/STANDARD FORCE	MINIMUM: 01 = 10%	MAXIMUM: 10 = 100%
-----------	---	--------------------------	---------------------------

During **STANDARD TIME A1** the force of **motor A** is **A5** % of the total. The force of **motor A** can be set **from 10% to 100%** in steps of **10%**. The force of the motor increases or decreases the sensitivity of the obstacle sensor: the greater the force set, the lower the sensitivity; the lower the force set, the higher the sensitivity.

A6	TORQUE ADJUSTMENT/STANDARD FORCE	MINIMUM: 01 = 10%	MAXIMUM: 10 = 100%
-----------	---	--------------------------	---------------------------

During **SLOWDOWN TIME A2** the force of **motor A** is **A6** % of the total. The **SLOWDOWN FORCE** can be set **from 10% to 100%** in steps of **10%**. The force of the motor increases or decreases the sensitivity of the obstacle sensor. The greater the force set, the lower the sensitivity. The lower the force, the greater the sensitivity.

A7	STANDARD OBSTACLE	MINIMUM: 00 = 0%	MAXIMUM: n = disabled
-----------	--------------------------	-------------------------	------------------------------

If the force of **motor A** detected is greater than the **STANDARD OBSTACLE THRESHOLD A7** set, during **STANDARD TIME A1** the control unit detects an obstacle. If the force of **motor A** detected is greater than the set threshold, the gate reverses the movement if it is the first detection in the working cycle, otherwise it goes to the limit switch.

Once the obstacle is detected, the gate performs a safety procedure by moving one door at a time.

In order to facilitate calibration of the **STANDARD OBSTACLE THRESHOLD**, the control unit's display during opening shows the force of **motor A** as a number from **00** to **99**. To disable obstacle detection press the **(+) KEY** until the display shows **n**.

A8	SLOWDOWN OBSTACLE THRESHOLD	MINIMUM: 00 = 0%	MAXIMUM: n = disabled
-----------	------------------------------------	-------------------------	------------------------------

During the **SLOWDOWN TIME A2** the control unit detects an obstacle if the force of the motor is greater than the **SLOWDOWN OBSTACLE THRESHOLD A8** set. Obstacle detection during slowdown acts as a limit switch. In order to facilitate calibration during **OPENING**, the display of the control unit shows the force of **motor A** as a number from **00** to **99**. To disable obstacle detection during slowdown press the **(+) KEY** until the display does not show **n**.

OBSTACLE SENSOR PROGRAMMING

P6

AUTOMATIC OBSTACLE SENSOR PROGRAMMING

This procedure allows the obstacle sensor parameters of **motor A** and **motor B** to be programmed.

The parameters in question are:

A7 → **STANDARD OBSTACLE THRESHOLD MOTOR A**

A8 → **SLOWDOWN OBSTACLE THRESHOLD MOTOR A**

b7 → **STANDARD OBSTACLE THRESHOLD MOTOR B**

b8 → **SLOWDOWN OBSTACLE THRESHOLD MOTOR B**

P6	Select the automatic sensor programming using the (←) (→) KEYS .
--	After a few seconds the display shows two underscores: send a START order to start the procedure.
1	The display shows 1 : the motors close by pushing on the stop. The control unit is detecting the force of the motor in the presence of obstacles in both STANDARD and SLOWDOWN modes. <i>The control unit automatically switches to step 2.</i>
2	The display shows 2 : motor A opens and then slows down. When motor A stops, motor B opens and then slows down. The control unit is detecting the force of the motors in the absence of obstacles. <i>The control unit automatically switches to step 3.</i>
3	The display shows 3 : the motors close first motor B and then motor A in turn. The control unit is resetting to the start position (GATE COMPLETELY CLOSED).

At the end of the procedure, if the control unit shows **9P**, the programming was not successful on some or all of the parameters. To check parameters that have not been programmed, select in turn the parameters affected by programming and check their value. If they are set to n, that parameter has not been programmed. Changing the force of the motor may change the programming result.

Example:

When programming is complete, the display shows **9P**. Suppose that the normal force of **motor B** has not been programmed. The numbers given in the example are for illustration purposes only and may vary from installation to installation.

- At the end of procedure **P6** the control unit shows **9P**
- Using **KEYS** (←) (→) select the parameter **A7**
- Parameter **A7** = **47**: the **STANDARD OBSTACLE THRESHOLD** of **motor A** has been correctly programmed.
- Using **KEYS** (←) (→) select the parameter **A8**
- Parameter **A8** = **81**: the **SLOWDOWN OBSTACLE THRESHOLD** of **motor A** has been correctly programmed.
- Using **KEYS** (←) (→) select the parameter **b7**
- Parameter **b7** = **n**: the **STANDARD OBSTACLE THRESHOLD** of **motor B** has NOT been programmed.
- Using **KEYS** (←) (→) select the parameter **b8**
- Parameter **b8** = **65**: the **SLOWDOWN OBSTACLE THRESHOLD** of **motor B** has been correctly programmed.
- At the end of this analysis, the only uncalibrated parameter was **b7**. Parameter **b7** is linked to the normal phase of **motor B**. Therefore, by **modifying** the **NORMAL FORCE** of **motor B** **b5** a repetition of the procedure can be attempted.
- Using **KEYS** (←) (→) select the parameter **b5**.
- Using the (-) **KEY** decrease the force of **motor B** by 1 or more units (each unit corresponds to 10%).
- Repeat this procedure **P6**.
- Repeat this operation until it is determined **b7**

The sensitivity of the obstacle sensor is determined by the **FORCE** setting rather than the detection threshold.

Generally, error **9P** is linked to a force that is too high in relation to the gate in use. However, the procedure may also fail because the force setting is too low in relation to the system in use.

GENERAL FUNCTIONS

There are many functions that allow the operation of the gate to be customised. These are identified within the menu by the letters **F** and **L**.

sec = seconds **%** = percentage parameter **n** = disabled **xxx** = see full description

Times are expressed in seconds

Forces and thresholds are expressed in decimals and correspond to %. Ex: **01** = 10%

F0	AUTO-CLOSE TIME	10 sec	F8	PHOTOCELLS LOGIC: SLIDING	n (y/n)
F1	PEDESTRIAN TIME	7 sec	L0	ELECTRIC LOCK - FLASHING LIGHT 12VDC	0
F2	KICK BACK FUNCTION AT CLOSING	0,0 sec	L1	MOTOR HEATING/OIL RECYCLING	0 min
F3	PRE-BLINKING TIME	1,0 sec	L3	ONLY MOTOR A MODE	n (y/n)
F4	KICK BACK FUNCTION AT OPENING	n (y/n)	L4	RESTORING MANOEUVRE WITH DEAD MAN FUNCTION	n (y/n)
F5	STEP-BY-STEP MODE	n (y/n)	L5	WORKING CYCLES LIMIT - MAINTENANCE REQUEST	n
F6	MULTIPLE RESIDENTS MODE	n (y/n)	L6	TOTAL WORKING CYCLES COUNTER	xx
F7	FAST CLOSURE	n (y/n)			

F0	AUTO-CLOSE TIME	MINIMUM: 00 sec	MAXIMUM: 99 sec
-----------	------------------------	------------------------	------------------------

After opening, the gate remains fully open for **F0** seconds. At the end of this time, the gate begins to close. To disable the **AUTOMATIC CLOSE TIME** keep the (+) **KEY** pressed down for a long time, until the display shows **5E**. If automatic closing is disabled, the gate remains open after opening has finished.

F1	PEDESTRIAN TIME	MINIMUM: 00 sec	MAXIMUM: A1 sec
-----------	------------------------	------------------------	------------------------

In the event that the gate is started by a **PEDESTRIAN** order, **F1** represents the working time of **motor A**. The slowdown will not be performed during the opening phase, but will be performed during the closing phase. During a **PEDESTRIAN** operation, **motor B** is not activated. A **START** order interrupts the **PEDESTRIAN** operation and also starts **motor B**. During a standard working cycle, the **PEDESTRIAN** order behaves exactly like a **START** order.

F2	KICK BACK	MINIMUM: 00 sec	MAXIMUM: 25 sec
-----------	------------------	------------------------	------------------------

At the end of the closing process, after having performed any slowing down phase, **motor A** pushes on the stop at maximum force for **F2** seconds. This function can be useful when using the electric lock, when closing is difficult. During this operation, the obstacle sensor is disabled

F3	PRE-BLINKING TIME	MINIMUM: 00 sec	MAXIMUM: 50 sec
-----------	--------------------------	------------------------	------------------------

Before starting an opening or closing operation, the gate waits for **F3** seconds.

F4	KICK BACK	MINIMUM: n	MAXIMUM: 4
-----------	------------------	-------------------	-------------------

By enabling parameter **F5 = 4** before opening, **motor A** closes for 0.5 seconds. During this time the force of the motor is at its maximum and the obstacle sensor is disabled. This function can be useful to help release the electric lock.

F5	STEP-BY-STEP MODE	MINIMUM: n	MAXIMUM: 4
-----------	--------------------------	-------------------	-------------------

Enabling parameter **F5 = 4** activates the **STEP-BY-STEP** mode: during the opening and closing phase, the **START** orders stop the movement. A subsequent **START** order will start the movement in the opposite direction to the one that was interrupted. For example: if the gate is opening, a **START** order stops the opening. The subsequent **START** order starts the closing phase of the gate.

F6	MULTIPLE RESIDENTS MODE	F5 = n	F6 = n
-----------	--------------------------------	---------------	---------------

Enabling parameter **F6 = 4** activates the **MULTIPLE RESIDENTS** mode: during the **OPENING** phase, the **START** orders do not block the operation. During the closing phase, the **START** orders reverse the movement (from **CLOSING (→) OPENING**). Multiple residents mode has higher priority than **STEP-BY-STEP** mode. By setting **F6 = 4** it will no longer be possible to change the value of **F5** which will be automatically disabled (**n**).

	STANDARD MODE	MINIMUM: 00 = 0%	MAXIMUM: n = disabled
--	----------------------	-------------------------	------------------------------

If both **STEP-BY-STEP** and **COMMUNITY** modes are disabled (**F5 = n, F6 = n**) the operating logic of the control unit is **STANDARD**: during opening, the **START** orders stop the movement of the gate. During closing, the **START** orders reverse the movement.

GENERAL FUNCTIONS

F7	FAST CLOSURE	MINIMUM: 0	MAXIMUM: 4
-----------	---------------------	-------------------	-------------------

The **FAST CLOSURE** function allows the gate to be closed after passing in front of both photocells (open and close or close and open). Closing begins 5 seconds after passing in front of the photocells. This function is only enabled once per **WORKING CYCLE** and if the gate movement is not interrupted.

If **F7** = all **START** orders initiate this function: the remote controls stored with the functions **r1 START**, **r3 PEDESTRIAN**, **r4 FAST CLOSURE**, the terminal board inputs associated with the **START** **Co**, **OPEN** **oP** or **PEDESTRIAN** functions **PE**. If **F7** = 0 (disabled) only remote controls stored with the radio function **r4** activate the **FAST CLOSURE**.

F8	PHOTOCELLS LOGIC: SLIDING	MINIMUM: 0	MAXIMUM: 4
-----------	----------------------------------	-------------------	-------------------

If **F8** = 4 the photocells operate with the logic of **SWING GATE** automation:

- **OPENING PHOTOCELLS** (terminal 13 parameter **E5 = EA**): suspend the **OPENING** as long as the beam is interrupted. Reverses the movement status from **CLOSING** to **OPENING SUSPENDED**. During **OPENING** they have no effect on the ongoing operation.
- **CLOSING PHOTOCELLS** (terminal 12 parameter **E4 = EC, E4 = ED**): reverse the movement from **CLOSING** to **OPENING**.

If **F8** = 0 the photocells operate with the logic of **SLIDING** automation:

- **OPENING PHOTOCELLS** (terminal 13 parameter **E5 = EA**): during **OPENING** they reverse the movement for 3 seconds. After these 3 seconds, **CLOSING** is interrupted. A subsequent **START** order starts the gate in **CLOSING** mode.

They have no effect during the **CLOSING** operation.

- **CLOSING PHOTOCELLS** (terminal 12 parameter **E4 = EC, E4 = ED**): reverse the movement from **CLOSING** to **OPENING**. They have no effect during the **OPENING** operation.

L0	KICK BACK	MINIMUM: 0	MAXIMUM: 3
-----------	------------------	-------------------	-------------------

This parameter allows changes to be made to the operating logic of terminals 20 + e 21 - (**L0**) associated with the electric lock. This output is useful for controlling a 12VDC electric lock or a 3 W 12 VDC LED flashing light. The output of the electric lock can also be controlled by remote control.

L0 = 00 → The output is disabled. Only remote controls associated with the function **EL** (activate the electric lock for 3 seconds) can activate the control unit's output 20 + e 21 - (**L0**). The activation of the electric lock by remote control can be useful to manage a pedestrian gate adjacent to the automatic gate.

L0 = 01 → The output is enabled to manage an electric lock installed on the door moved by motor A. At the beginning of each **OPENING** movement, the control unit releases the electric lock. Remote controls stored as **EL** unlock the electric lock.

L0 = 02 → The output is enabled with an intermittent flashing function. During **OPENING**, the flashing light will perform fast flashes. During **CLOSING** the flashes will be slow. During the automatic closing time, the flashing light is permanently lit.

L0 = 03 → The output is enabled with the steady light function during the operation. During **OPENING**, **CLOSING** and the **AUTOMATIC CLOSING TIME** the flashing light is on.

L1	OIL RECYCLING / MOTOR HEATING	MINIMUM: 0 min	MAXIMUM: 8 min
-----------	--------------------------------------	-----------------------	-----------------------

With this function it is possible to heat the motors and the control unit box cyclically. In the case of systems with hydraulic motors, it is useful to circulate the oil periodically: each cycle lasts 10 minutes and **L1** represents the minutes that the motor/box is heated in each cycle. This function is activated after 10 minutes with the gate fully closed or open: any operation on the control unit or interruption of a photocell resets the time count to zero. The motors are active in the final part of each cycle. For example, by setting **L1 = 03** the motors remain switched off for 7 minutes and then switched on for the remaining 3 minutes after the function is active (i.e. after 17 minutes from the last operation performed).

L3	ONLY MOTOR A MODE	MINIMUM: 0	MAXIMUM: 4
-----------	--------------------------	-------------------	-------------------

By enabling this function **L3 = 4** only motor A will be managed. The parameters relating to motor B (**b1 - b8**) can no longer be modified. This function is useful when installing a 1 door swing gate or sliding gates. If this control unit is used on a sliding gate, set parameter **F8 = 4** to select the correct photocell logic.

GENERAL FUNCTIONS

L4	RESTORING MANOEUVRE WITH DEAD MAN FUNCTION	MINIMUM: n	MAXIMUM: 9
-----------	---	-------------------	-------------------

This function, if enabled, **L4 = 9** allows the gate to be opened or closed if one of the safety devices (photocells or stop) breaks down, allowing passage until the fault is repaired. This mode requires the installation of a **START** device (normally open contact) on terminal block 9 or terminal block 10 and the setting of its management parameter (**E1** or **E2**) to one of the following functions: **Go** start, **oP** open or **cL** close. If the conditions described above are met and a safety device (stop, external or internal photocell) has been active for more than 5 seconds, then it is possible to operate the gate in opening/closing mode using this procedure:

1. Activate the **START** device
2. Deactivate the **START** device

The flashing lights turn on (only if configured on terminals 20 + e 21 - (**L0**) via function **L0 = 02** or **L0 = 03**).

3. Activate the **START** device within 2.5 seconds of the flashing light coming on. The control unit shows the countdown from 2.5 to 0 seconds on the display.
4. The gate will perform the required operation (opening/closing) as long as the **START** device is kept active. When the **START** device is deactivated, the control unit blocks the movement of the gate.

L5	WORKING CYCLES LIMIT - MAINTENANCE REQUEST	MINIMUM: n	MAXIMUM: 59
-----------	---	-------------------	--------------------

Parameter **L5** allows the number of working cycles before maintenance to be set. When the gate has performed **L5** operation, the time for flashing will be set to 5 seconds. This function can be useful for alerting the end user to the need for system maintenance. The parameter **L5** can be set in these ranges:

n = disabled

- from **0.1** to **09** from 1 to 9 working cycles
- from **1.1** to **19** from 10 to 90 working cycles
- from **2.1** to **29** from 100 to 900 working cycles
- from **3.1** to **39** from 1000 to 9000 working cycles
- from **4.1** to **49** from 10000 to 90000 working cycles
- from **5.1** to **59** from 100 000 to 900 000 working cycles

How to read the display:
 the first digit indicates the exponent of the power of 10, the second its multiplier.
For example:
 3.3 indicates 103 x 3 = 3,000
 2.9 indicates 103 x 9 = 900
 5.1 indicates 105 x 1 = 100,000

Pressing any key on the control unit sets the counter to 0 and this function will only be activated again after **L5** cycles.

L6	WORKING CYCLES COUNTER	MINIMUM: 0.1	MAXIMUM: 69
-----------	-------------------------------	---------------------	--------------------

Parameter **L6** cannot be changed or deleted and represents the number of working cycles of the automatic gate. Once the parameter **L6** has been selected (see the **MENU NAVIGATION** page) the most significant decimal number of the counter is shown in the format **POSITION, VALUE**. By pressing the **(-) KEY** the display switches off.

Once the **(-) KEY** is released the scanning of the counter begins displaying its decimal position (value to the left of the dot) and its value (to the right of the dot).

EXAMPLE:

if a gate has performed 6258 operations, once **L6** has been selected the display shows: **36** by pressing the **(-) KEY** the display switches off. By releasing the **(-) KEY** the display will show in sequence:

multiplier:	*1000	*100	*10	*1	
position:	3	2	1	0	
	36	22	15	08	
value:	6	2	5	8	= 1000*6 + 100*2 + 10*5 + 1*8

The display changes screen to the next position approximately every 3 seconds, switching off briefly before showing the new number.

TESTS

Within the menu, test functions are identified by the letter **t**

t 1 PHOTOCELLS TEST n (y/n)

t MOTORS TEST n (y/n)

t 1	PHOTOCELLS TEST	MINIMUM: n	MAXIMUM: y
------------	------------------------	-------------------	-------------------

Before enabling this function (**t 1 = y**), check that the negative of the **PHOTOCELL TRANSMITTERS** is connected to **terminal 19 label t1**. Connect **ONLY** the negatives of the **TRANSMITTERS to terminal 19** and no other signals.

Before starting a closing or opening operation, the control unit removes power from the photocells checking that the contact is open. Once the opening of the contact has been checked, the control unit supplies the photocells again, checking the closure of the contact (the photocells are associated with signals type **N.C. NORMALLY CLOSED**).

If the check is successful, the required operation is started. If the check fails, the control unit display will indicate **t** and the gate will not be started. The photocell test will only be carried out on installed photocells.

For example: if the system only uses the photocell when closing, ensure that parameter **E4** is set to **tc** or **td** (functions relating to the photocell) and that the parameter **E5** is disabled (**E5 = n** - see "GENERAL FUNCTIONS").

In this way, the control unit will know which terminal the photocell is connected to and will not carry out the test on the unused terminal.

t 2	MOTORS	MINIMUM: n	MAXIMUM: y
------------	---------------	-------------------	-------------------

Before each operation, the control unit carries out the test of **motor A** and the test of **motor B**.

If the test is successful, the requested operation is started. If the test fails, the display shows:

- **9A error motor A**
- **9b error motor B**

The motor test fails in 4 cases:

- Motor **THERMAL CUTOFF TRIGGERED**
- **CONNECTION ERROR**
- Worn-out of the **COMPENSATION CAPACITOR** or breakdown of the control unit **TRIAC**.

REMOTE CONTROLS CONFIGURATION

This function is only available for the model WITH RADIO MODULE (APE-570/0510)

The remote controls can be configured using radio functions, which are identified on the display by the letter **r**.

r0 REMOTE CONTROL DELETION	r5 DELETE ALL REMOTE CONTROLS	Po OPEN DEAD MAN
r1 START	r6 PROGRAMMABLE FUNCTION	Pc CLOSE DEAD MAN
r2 STOP	r7 PROGRAMMABLE FUNCTION	G0 START
r3 PEDESTRIAN	r9 PLUG-IN RADIO MODULE	
r4 FAST CLOSURE		

r1 r2 r3 r4 r6 r7 STORE A REMOTE CONTROL

Up to 99 remote controls can be stored on the control unit. The remote control code is stored in the control unit (not in the radio module). If a remote control is to be deleted in the future, it is advisable to make a note of the memory allocation number for each user.

To store a remote control, select one of the available functions:

r1 START, **r2** STOP, **r3** PEDESTRIAN, **r4** FAST CLOSURE, **r6** PROGRAMMABLE FUNCTION or **r7** PROGRAMMABLE FUNCTION

Having selected the function, after about 2 seconds, the display shows =_. Keep the **REMOTE CONTROL KEY** pressed down and simultaneously press the **(+) KEY** on the control unit. When a remote control is transmitting, the display indicates this by lighting up a dot on the display. Once the remote control has been memorised, the control unit displays its identification number in the ID memory (from 0 to 99). The identification code is useful for deleting the remote control using the function **r0**. The remote control identification number is shown each time the stored remote control is transmitted and only after having selected one of the radio parameters **r1, r2, r3, r4, r6** or **r7**. If the key on the remote control is pressed when the control unit is in **STAND BY - -** the message of the function with which it is associated is displayed.

SAVING A REMOTE CONTROL AS START

1. Select the parameter **r1** using the scroll keys (←) or (→).
2. After a few seconds the display shows =_.
3. Hold down the button on the remote control to be stored. The display shows = . _
4. Press the **(+) KEY** on the control unit. The display shows = **1**. The remote control **has been successfully stored** in position 1 of the control unit memory (display = **2** memory position 2, display = **3** memory position 3, etc. up to 99).
 - 4a. If the display shows = . , the remote control has not been stored.
 - 4b. If the display doesn't show = . , the remote control was not received (e.g.: different frequency from the receiver), or the radio receiver is faulty.

r0 DELETE A REMOTE CONTROL

To delete a remote control it is necessary to know its ID (IDENTIFICATION number) or, vice versa, it is necessary to know the ID of the remote controls you do not want to delete. To find out the ID of a remote control, select one of the following radio parameters **r1, r2, r3, r4, r6** or **r7**. Press the button on the remote control: the display will show its identification number.

To delete a remote control, select parameter **r0**. After a few seconds, the display shows in sequence the identification numbers of the remote controls in the control unit's memory. Once the ID of the remote control that is to be deleted is displayed, press and hold the **(+) KEY** on the control unit. The display starts flashing and continues to show the ID number. Continue to hold down the **(+) KEY** until the display turns off (approx. 2 seconds). The remote control has been deleted.

EXAMPLE: DELETE THE REMOTE CONTROL WITH IDENTIFICATION NUMBER 3

1. Select the parameter **r0** using the scroll keys (←) or (→).
2. After 2 seconds the control unit shows =
3. After 2 seconds the control unit shows = **1**
4. After 2 seconds the control unit shows = **2**
5. After 2 seconds the control unit shows = **3**
6. Press and hold down the **(+) KEY**
7. The display starts flashing showing = **3**. Keep holding down the **(+) KEY**
8. After about 2 seconds the display turns off, the remote control has been deleted.

REMOTE CONTROLS CONFIGURATION

This function is only available for the model WITH RADIO MODULE (APE-570/0510)

r5

DELETE ALL REMOTE CONTROLS

To delete all the remote controls, select the parameter r5.

After about 2 seconds, the control unit displays r. Hold down the (+) KEY. The display starts flashing showing y.

When the display shows y without flashing, then **ALL** previously stored remote controls have been **DELETED**.

r6 r7

PROGRAMMABLE FUNCTION

The remote controls stored via the functions r6 and r7 can be associated with different functions:

Po DEAD MAN OPENING, **Pc DEAD MAN CLOSING**, **oP OPEN**, **cL CLOSE**, **EL ACTIVATE ELECTRIC LOCK** for 3 seconds, **do ACTIVATE PROGRAMMABLE OUTPUT** (see parameters o1 and o2 in the section of the manual describing programmable outputs). To save a remote control that can be associated with a programmable function, proceed as described in the **STORE A REMOTE CONTROL** paragraph. To **ASSOCIATE A NEW FUNCTION**, select parameter r6 or r7. Hold down the (-) KEY. The display starts flashing showing r6 or r7. When it stops flashing, release the (-) KEY. Change the function using the (+) KEY.

The function initially associated with r6 is **Po DEAD MAN OPENING**. The function initially associated with r7 is **Pc DEAD MAN CLOSING**.

r9

PLUG-IN RADIO

The "PLUG-IN RADIO MODULE" section is dedicated to both models (APE-570/0510 - APE-570/0511).

To store or delete a remote control on the plug-in radio module, refer to the manual provided by the manufacturer of the **RADIO**.

It is possible to change the function engaged by the remote controls stored on the plug-in radio module. To change the function of the radio, select parameter r9. After 2 seconds, the display shows the associated function. Use the (+) KEY or the (-) KEY to change the function.

Remote controls stored on the plug-in radio module can be associated with one of these functions:

r DISABLED, Co START, oP OPEN.


Remote controls stored on the plug-in radio module are not stored in the control unit memory.

PROGRAMMABLE OUTPUTS

The management parameters of the programmable outputs can be identified in the menu by the letter **o**.

In order to use these functions, **RELAY** expansion modules (*APE-570/0022*) need to be connected to the connection pins on the control unit:

Example: connection of two 230 Vac lights



o1 o2

PROGRAMMABLE OUTPUTS 1

The programmable functions on the outputs are as follows:

o1: GATE OPEN INDICATOR LIGHT

The output is active when the gate is OPEN. As soon as the gate is **COMPLETELY CLOSED**, the output is deactivated.

o2: GATE CLOSED INDICATOR LIGHT

The output is active when the gate is **COMPLETELY CLOSED**. As soon as the gate is no longer closed it is deactivated.

o3: INTERMITTENT FLASHING LIGHT

The output is not active when the gate is stopped. The output is deactivated and activated intermittently when the gate is in motion. During opening it is deactivated and activated faster than during closing. During **AUTO-CLOSE TIME** (the gate is fully open and will close automatically after **F0** seconds) the output is active. With this function it is possible to use the flashing light both to distinguish the working phase of the gate and to signal the current or future operation of the automatic gate.

o4: COURTESY LIGHT

The output is activated for 3 minutes each time the gate starts an opening operation.

o5: "ON/OFF" BY REMOTE CONTROL STORED AS r6

The output status is switched whenever a remote control stored as r6 is transmitting. This function is useful for operating a light controlled by a remote control button.

o6: "ON" WHILE A REMOTE REMOTE STORED AS r6 IS TRANSMITTING

The output is active whenever a remote control stored as r6 is transmitting. This function can be useful for controlling an electric lock through a radio device, or for signalling a dead man opening/closing movement.

o7: "ON/OFF" BY REMOTE CONTROL STORED AS r7

The output status is switched whenever a remote control stored as r7 is transmitting. This function is useful for operating a light controlled by a remote control button.

o8: "ON" WHILE A REMOTE REMOTE STORED AS r7 IS TRANSMITTING

The output is active whenever a remote control stored as r7 is transmitting. This function can be useful for controlling an electric lock through a radio device, or for signalling a dead man opening/closing movement.

PROGRAMMABLE OUTPUTS

ALL EXAMPLES ASSUME THAT THE PLUG-IN RELAY EXPANSION MODULE (APE 570/0022) HAS BEEN CONNECTED TO THE CONTROL UNIT'S OUTPUT PINS.

EXAMPLE: remote control configuration for controlling a light

1. Store a remote control as **r6**.
2. Select the parameter **r6** again.
3. Press and hold down the **(-) KEY** on the control unit. The display starts flashing showing **r6**.
4. When the display shows **r6** without flashing, release the **(-) KEY**.
5. Using the **(+)(-) KEYS**, select the **do** function.
6. Using **(←) (→) KEYS** select the parameter **o1 / o2**.
7. Using the **(+)(-) KEYS**, select the **05** function.
8. Exit the menu using the **(←) (→) KEYS**.

The remote control stored by performing this procedure will switch the output status without changing the gate status.

EXAMPLE: configure a remote control to signal a dead man opening movement

1. Store a remote control as **r6**.
2. Select the parameter **r6** again.
3. Press and hold down the **(-) KEY** on the control unit. The display starts flashing showing **r6**.
4. When the display shows **r6** without flashing, release the **(-) KEY**.
5. Using the **(+)(-) KEYS**, select the **PO** function.
6. Using **(←) (→) KEYS** select the parameter **o1 / o2**.
7. Using the **(+)(-) KEYS**, select the **06** function.
8. Exit the menu using the **(←) (→) KEYS**.

When the remote control button, stored following the above procedure, is transmitting, the gate will move in the **OPEN** direction and simultaneously the output will be activated.

EXAMPLE: configure a remote control to signal a dead man closing movement

1. Store a remote control as **r7**.
2. Select the parameter **r7** again.
3. Press and hold down the **(-) KEY** on the control unit. The display starts flashing showing **r7**.
4. When the display shows **r7** without flashing, release the **(-) KEY**.
5. Using the **(+)(-) KEYS**, select the **PC** function.
6. Using **(←) (→) KEYS** select the parameter **o1 / o2**.
7. Using the **(+)(-) KEYS**, select the **08** function.
8. Exit the menu using the **(←) (→) KEYS**

When the remote control button, stored following the above procedure, is transmitting, the gate will move in the **CLOSE** direction and simultaneously the output will be activated.

EXAMPLE: transforming a 230VAC light into a intermittent flashing light

1. Using **(←) (→) KEYS** select the parameter **o1 / o2**.
2. Using the **(+)(-) KEYS**, select the **03** function.
3. Exit the menu using the **(←) (→) KEYS**

The lamp will turn on and off quickly during opening, slowly during closing and will remain on during the **AUTO-CLOSE TIME**.

PRODUCT DISPOSAL



A) Declaration for household EEE without batteries or portable accumulators

INFORMATION FOR USERS OF DOMESTIC OR PROFESSIONAL EQUIPMENT

Pursuant to Art. 26 of Italian Legislative Decree No. 49 of 14 March 2014 "Implementation of Directive 2012/19/EU on waste electrical and electronic equipment (WEEE)"

The crossed-out wheeled bin symbol on the equipment or its packaging indicates that the product must be collected separately from other waste at the end of its useful life to enable proper treatment and recycling. The user must, therefore, return the end-of-life equipment free of charge to the appropriate municipal centres for the separate collection of electrical and electronic waste, or return it to the retailer as follows:

- for very small appliances, i.e. with at least one external side not exceeding 25 cm, free delivery with no obligation to buy is provided by shops with a sales area for electrical and electronic equipment of more than 400 m². For smaller shops, this is optional.
- for appliances larger than 25 cm, delivery is provided to all points of sale on a 1-for-1 basis, i.e. delivery to the retailer can only take place on the purchase of a new equivalent product on a one-for-one basis.

Appropriate separate collection for subsequent recycling, treatment and environmentally sound disposal of discarded equipment contributes to avoiding possible negative effects on the environment and health and promotes the reuse and/or recycling of the materials from which the equipment is made.

Unauthorised disposal of the product by the user will result in the application of sanctions in accordance with current legislation.

Abexo[®]

AUTOMATION ACCESSORIES

ABEXO is a registered trademark property of
AB TECNO srl - Via Cicogna 95
40068 San Lazzaro di Savena (BO)
info@abtecno.com
www.abexo.tech