

# Tabella di compatibilità

## *Compatibility table*

<b>Marca</b> <i>Brand</i>	<b>Frequenza</b> <i>Frequency</i>	<b>Modello</b> <i>Model</i>
ADYX	433.920	ALIZE EM2C, ALIZE EM4C
AETERNA	433.920	TX433 1,2,4 buttons
ALLMATIC	433.920	AEMX1, AEMX2, AEMX4
ALLMATIC	433.920	EUROPE AUTO ARMY2, ARMY1, ARMY4
ALLMATIC	433.920	MX1, MX2, MX4
ALLTRONIC	433.920	S429_1, S429_2, S429_4, S429_M
ALLTRONIC	433.920	S425
ANSONIC	433.920	SA 434-1E, SA434-2E, SA434-3E, SA434-4E
ANSONIC	433.920	SA 434-1MINI, SA434-2MINI, SA 434-2Midi
APERTO	433.920	CPS1, CPS2, CPS4
AVIDSEN	433.920	100601 micromark MM23164
AVIDSEN	433.920	100951, 100955, 100550, 100400
B&D BnD BD	433.920	062170/4333EBD, 062171, 4333°
B&D	433.920	PTX4 059120 / 059116
B&D	433.920	062170/4333EBD 1A4982 10 trinary
BANDY	433.920	
BELFOX	433.920	DHS433-1, DHS433-2, DHS433-4, dip switch version
BELFOX	433.920	DHS 433,92 (7733), dip switch version
BENINCA'	433.920	LOT1W, LOT2W, LOT4W
BENINCA'	433.920	LOT2WMS
BENINCA'	433.920	T2WK, T4WK

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
BENINCA'	433.920	LOTX1W, LOTX2W, LOTX4W
BENINCA'	433.920	TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK
BESIDE	433.920	BEZAP
BESIDE	433.920	HIT
BFT	433.920	TE01, TE02 ( TE01, TE02 )
BFT	433.920	TE04 ( TEO4 )
BFT	433.920	MITTO 2/4 TRC2/4
BFT	433.920	MITTO 2, MITTO 4: Solo se il ricevitore è CLONIX1 o CLONIX 2 con DIP2 in posizione ON
BREDA	433.920	Breda TOP432SA
CAME	433.920	T432, T434, TOP432A, TOP434A, TOP432, TOP432NA, TOP434NA
CAME	433.920	TOP432M, TOP434M
CAME	433.920	TAM432SA
CAME	433.920	TOP432SA
CAME	433.920	TOP432NA
CAME	433.920	TWIN2, TWIN4
CAME	433.920	CAME TOP-432EV, TOP-434EV
CARDIN	433.920	S438-2
CARDIN	433.920	S476 TX2, S476TX
CASALI GENIUS	433.920	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433
CASIT	433.920	ERTS92B, ERTS92T
CASIT	433.920	ERTS20DB, ERTS20DQ
CASIT	433.920	ERTS476D, ERTS476Q
CASIT	433.920	TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T
CELINSA	433.920	S10 1, S10 2, SAW1, SAW2
CENTURION	433.920	CLASSIC, SMART, SMART2

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTMAN	433.920	4330E, 4332E, 4333E 4335E
CPS	433.920	TCP3, CPS, Jolly 4
CPS	433.920	CPS1 TCP3, CPS2 TCP3, CPS4 TCP3, EM1CV, EM2CV, EM4CV
CRAWFORD	433.920	TX-433
DASPI	433.920	Happy2, Pops2Ã,
DASPI	433.920	Daspi Zero2, Zero2CLO, Zero4CLO
DEA	433.920	433 1, 433 2, 433 4
DEA	433.920	Genie
DEA	433.920	Punto S2
DEA	433.920	Dea MIO TD2, MIO TD4
DELMA	433.920	Mizard 433 1, Mizard 433 2
DELMA	433.920	King 433 2
DELMA	433.920	Style Copy 2CH (this is a code duplicator)
DICKERT	433.920	MAHS433 01, MAHS433 04 non possiamo garantire che può essere duplicato, poiche dipende dal ricevitore.
DICKERT	433.920	S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000 possono essere duplicati solo i modelli con pulsanti rossi
DICKERT	433.920	S5-433-A2L00, S5U-433-A2L00 possono essere duplicati solo i modelli con pulsanti rossi
DITEC	433.920	GOL4C
DOITRAND FDOITRAND	433.920	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E_GRISE
DOITRAND FDOITRAND	433.920	TS2DE, TS4DE
DOORHAN	433.920	
DOORMATIC	433.920	SAW
DUCATI ALLDUCKS	433.920	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4, RONDY TSAW1, RONDY TSAW2, RONDY TSAW3

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
DUCATI ALLDUCKS	433.920	TPR10-A, TPR20-A, RONDY TPR10_A, RONDY TPR20_A
DUCATI ALLDUCKS	433.920	TE2
DUCATI ALLDUCKS	433.920	HC6203, 6203: only blue , red and transparent
ELBE	433.920	501, 502, 504
ELBE	433.920	502a, 504°
ELBE	433.920	502, 504
ELCA	433.920	IRIS, IRIS 9CH Both colors red and blu
ELCA	433.920	ASTER2
ELCA	433.920	Aster 1000, Aster1001 Colors: black, blue, light grey
ELCA	433.920	GEMINI 9CH
ELCA	433.920	VIRGO
ELDAT MFZ	433.920	Eldat RT20-4103M-01, RT20-4104M-01, RT354104M-01, RT21-4101M-01, RT21-4102M-01
ELDAT MFZ	433.920	Eldat RT28-4101M-01, RT27-4101M-01, RT26-4101M-02, RT21-4125M-01, RT21-4139M-01, RT21-4139M-02, RT31-4139M-01, RT31-4139M-02, RTC02-4104M-01
ELVOX	433.920	
ELVOX	433.920	ET03, ET04
ERONE	433.920	SETDS39433E2, SETDS39433E4
ERREKA	433.920	Erreka Luna, Erreka SMAT 1 RESON 1, RESON 2, RESON 3
EUROPE AUTOMATISMES	433.920	ASMY1, ASMY2, ASMY4
EUROPE AUTOMATISMES	433.920	S1, S2, S3
FAAC	433.920	TM1 433 DS, TM2 433 DS, TM3 433 DS
FAAC	433.920	TML2 433 SLR, TML4 433 SLR, TML2-433-SLR, TML4-433-SLR
FAAC	433.920	TML2 433 SLP, TML4 433 SLP, TML2-433-SLP, TML4-433-SLP
FADINI/BPT	433.920	433 2M, Astro43_2m
FADINI/BPT	433.920	Astro433-2, Astro433-4, Astro43-2, Astro43-4

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
FERPORT	433.920	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr
FUNKMODUL ELSECO	433.920	T433A2K1, T433A2K2
FUNKMODUL ELSECO	433.920	T433A2K4, T433A2K4n
GIBIDI	433.920	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4
GRIFFON	433.920	Griffon 433 MHz dip switch remotes and duplicating remotes
GULLIVER	433.920	MDW 2E
HAUSS	433.920	Pocket 3750-1, Pocket3750-2, Pocket 3750-4
HORMANN	433.920	HSM2, HSM4, yellow buttons Please note that, in Netherlands, Hoermann sell this kind of remote control which transmit a rolling code: in this case it cannot be duplicated!
HORMANN	433.920	RS2-433, RS4-433 (Rolling code versions, usually sold in Netherlands)
HRC	433.920	
JAY	433.920	UBEI x1 SL1
JAY	433.920	UBET 11, UBET 21, UBET 31, UBET 41, UBET, 61Ã
KEY AUTOMATION	433.920	900TXB-42, 900TXB-42N, 900TXP-42, 900TXP-42N
KEY AUTOMATION	433.920	900TXB-44, 900TXG-44
KEY AUTOMATION	433.920	900SUB-44, 900SUB-44N, 900SUB-44W, 900SUB-44WN
KEY AUTOMATION	433.920	900TXK-42, 900TXW-42,900TXK-44, 900TXW-44
LABEL IUPPITER	433.920	RJW/1E, RJW/2E, RJW/4E, RJW/12E
LABEL IUPPITER	433.920	MDW/1E, MDW/2E
LEB	433.920	TMW
LEB	433.920	TSAW2N, TSAW4N
LEB	433.920	TCP3Ã, (this is a code duplicator)
LEB	433.920	TRK4 Note: receiver should be configured to disable rolling check.
LEB	433.920	TPW4
LINCE	433.920	LR 2035

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
MA SYSTEM	433.920	MA TX1, MA TX2, MA TX3
MARANTEC	433.920	D101
MARANTEC	433.920	D12
MARANTEC	433.920	D212, D222, D232
MARANTEC	433.920	Digital 302, D302
MARANTEC	433.920	Digital 304, D30
MCZ	433.920	Aster
MEIÄfÅ,NER MEISSNER	433.920	LW433-1, LW433-2, LW433-4
MEIÄfÅ,NER MEISSNER	433.920	Pocket 3750 1, 2, 4
MONSEIGNEUR	433.920	ARC2, ARC4
MONSEIGNEUR	433.920	TDR 400 3845, TDR 400 3846, TDR 400 3847 T1SAW433, T2SAW433, T4SAW433
MOTORLINE STATEUROP	433.920	MX1, MX2, MX3, MX4, MX6 MX11, MX12, MX13
MOTOSTAR	433.920	CLIKSTAR2, CLICKSTAR4, CLICK-4M, CLICKSTAR RE 532, CLICKSTAR RE 534
NICE	433.920	FLO1, FLO2, FLO4
NICE	433.920	VERY VE
NICE	433.920	SMILO SM2, SM4
NOLOGO	433.920	ECO DIP
O&O, OeO, O and O	433.920	T-COM DS 4-2, T-COM DS 4-4
O&O, OeO, O and O	433.920	OeO TX4-E, TX2-E (red buttons)
OPENOUT	433.920	TMQ 433 2, TMQ 433 4
PIAZZETTA	433.920	4 buttons for wood/pellet heater
PORTAMATIC	433.920	MPH01, MPH02
POWERFIX Profi (Lidl)	433.920	RCB-A 3600R
PRASTEL	433.920	MPSTF2E, MPSTF4E
PRASTEL	433.920	Modelli rolling code

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
PROEM	433.920	ER2C4ACM, ER4C4ACM
PROGET	433.920	ETY_433N2, ETY 433N4
PROGET	433.920	EMI433-N2
PROTECO	433.920	TX433
PROTECO	433.920	EUROMATIC
PROTECO	433.920	HIT
PUJOL	433.920	
QUASAR	433.920	433 TANGO SLIM BLEU
QUICK	433.920	Model: 302
RIB	433.920	MOON-433
RIB	433.920	cod 433-1/2/3
RIB	433.920	Sun
ROGER	433.920	R80/TX12, R80/TX14, R80/TX12R, R80/TX14R
ROGER	433.920	H80/TX22
ROGER	433.920	G80/TX32, G80/TX34, G80/TX32R, G80/TX34R
SEA	433.920	
SEA	433.920	SMART433_TX2_DIP, SMART433_TX3_DIP, SMART433_TX2_COPY, SMART433_TX3_COPY Smart2 Dip Switch, Smart3 Dip Switch
SEAV	433.920	TXS1, TXS2, TXS3, TXS4
SEAV	433.920	Behappy S1, Behappy S2, Behappy S3
SEAV	433.920	Be Easy TX, Be Easy Murale2
SEAV	433.920	BeSmart S2, BeSmart S4
SEAV	433.920	BeFree S1
SECURVERA	433.920	SV R2C
SECURVERA	433.920	SV R4C

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
SECURVERA	433.920	SV R6C
SECURVERA	433.920	SV R2C
SENDER	433.920	
SERAI	433.920	OG/52, OG/54, OG/82, OG/84
SERAI	433.920	OG/28, OG/48, OG/62, OG/64
SERAI	433.920	OG/02, OG/04
SICE	433.920	TX4 CLACK Bigfoot
SILVELOX - INTRA	433.920	Silvelox Intra HSM4
SIMBA	433.920	Simba RC1
SIMINOR	433.920	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS
SMD	433.920	LW433-1, LW433-2, LW433-4 : AM models only
SOMFY	433.920	LEB TMW
STAGNOLI	433.920	ZEUS AZTR
STARTEC	433.920	TXQ2
TAU	433.920	250 SLIM, 250K-SLIM, 250K-SLIMC
TAU	433.920	250TXD2, 250TXD4
TAU	433.920	250BUG2, 250BUG4
TAU	433.920	250T-4, 250T-4C
TECNOMATIC	433.920	TQ433
TEDSEN BERNER GFA	433.920	SKX1MD, SKX2MD, SKX3MD, SKX4MD
TEDSEN BERNER GFA	433.920	SKX1KD, SKX2KD, SKX4KD, SKX6KD
TEDSEN BERNER GFA	433.920	SKX1DL, SKX2DL, SKX3DL, SKX4DL
TEDSEN BERNER GFA	433.920	SKX1LC, SKX2LC, SKX3LC, SKX4LC
TEDSEN BERNER GFA	433.920	SKX1SL, SKX2SL, SKX3SL, SKX4SL
TEDSEN BERNER GFA	433.920	SKJ



<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
TEDSEN BERNER GFA	433.920	SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD
TELCOMA	433.920	TANGO 2 SW, TANGO4 SW
TELCOMA	433.920	TANGO BLUE 2, TANGO 4 BLUE, TANGO BLEU 2, TANGO BLEU 4
TELCOMA	433.920	TANGO 2 N, TANGO 4 N
TELCOMA	433.920	TANGO 2 SLIM, TANGO 4 SLIM
TELCOMA	433.920	Telcoma Noire2, Noire4 (Note: Rolling-code jumper should be removed from the receiver!)
TELCOMA	433.920	TANGO WIN3
TELCOMA	433.920	TANGO2, TANGO4
TELCOMA	433.920	Telcoma EDGE 2, Telcoma EDGE 4
TKC	433.920	TSAW433
TORAG	433.920	S429 1, S429 2, S429 4
TORMATIC DORMA	433.920	HS, Dorma HS43 1E, HS43 2E, HS43 3E, HS43 4E
TORMATIC DORMA	433.920	MAHS, Siebau, Novoferm, Dorma
TORMATIC DORMA	433.920	MHS, MHS43-1
TREMA	433.920	TO93TV1, TO93TV2, TO93TV4
TUBAUTO	433.920	DIGITAL 101 433
V2	433.920	MATCH
V2	433.920	TCP3
V2	433.920	TCP3, ARC3
V2	433.920	TCP3
V2	433.920	TPR
V2	433.920	T1SAW/433, T2SAW/433, T4SAW/433
V2	433.920	TRR1, TRR2, TRR4
V2	433.920	PMR2, PMR4
VISONIC	433.920	WT 100, WT 100A, WT 101, WT 101A, WT 102, WT 104, WT 201, WT 201A, WT 201WP, WT 201AWP

<b>Marca Brand</b>	<b>Frequenza Frequency</b>	<b>Modello Model</b>
VSEG	433.920	CR SLIM
WAINE-DALTON	433.920	S429-1, S429-2, S429-4, S429-mini
WAINE-DALTON	433.920	S425
WECLA CDS	433.920	433, 433_2